

General Notes:

- The information provided here are guidelines only. Always adhere to Australian standards / BCA
- The installation and correct operation of these units in the installed situation is the responsibility of the installer. This includes but not limited to the correct flashing of doors and windows.
- Screw fixings must be used, DO NOT use nails
- 140
  The installed units must be plumb, square and level

Fixed Window				
ART NO. VARIOUS	PROJECT			
RAWN BY/DATE G 22/03/2019	REFERENCE		World Standard	
VARIES		SCALE @ A3 DNS	www.binq.com.au	REV
NISH/TREATMENT	.X ± 0.1 .XX ± 0.01 ± 0.25°	WEIGHT 1	THIS DRAWING IS THE PROPERTY OF BINQ. Information contained herein is confidential and is not to be used or disclosed to third parties without the written consent of bing $1/1$	A